

MC4000 FW Updater Mode

1. Power on the MC4000 while holding down **BACK & LOAD PREP**. The 4 Sampler pads will blink when the device is in firmware update mode.
 2. Connect the MC4000 to your computer via USB cable.
 3. Install and open the Denon DJ Firmware Updater 3.0
 4. Click File > Select Firmware, and choose the firmware .bin file
 5. Click Next.
 6. Wait until update process has completed.
 7. Once completed, power cycle the hardware.
- 