



## MPX16

Latest Firmware Version: v1.0.19

Release Date: August 18, 2015

### Firmware Update Instructions

**Warning:** During the following steps, do **not** remove the SD card or power MPX16 off. Doing so could damage it.

1. Unzip the contents of the **.zip** file to your Desktop.
2. Place the **MPX16UPD.DAT** and **MPX16UP2.DAT** files on the root (main) directory of an SD card (formatted to a FAT32 file system).
3. Insert the SD card into MPX16's **SD card slot**.
4. On your MPX16, press and hold both **Select +** and **Pad Edit**, power MPX16 on, and then release the buttons.
5. When prompted, press **Enter**. The unit will begin the firmware update.
6. Allow the update process to complete.
7. When the display shows **Complete**, power-cycle MPX16 (power it off then on again).
8. Congratulations—your MPX16 now has the newest firmware!

### Changes Since Firmware Version 1.0.18

- Fixes minor bugs.

### Technical Support

For additional help, visit [akaipro.com/support](http://akaipro.com/support)