

MCX8000 FW Update Instructions

1. Unzip the MCX8000 firmware archive file.
2. Copy the **MCX8000_FW.bin** file onto the root level of a USB thumb drive.
 - *The USB drive must be formatted as FAT32.*
 - *The **MCX8000_FW.bin** file must be on the root level of the drive and not inside of a folder.*
3. Insert the USB thumb drive into top **USB 1** port of the MCX8000.
4. Set the input switches of Channels 1 & 2 to the center Engine  position.
5. Power on the MCX8000.
6. Hold down the **VIEW** button to open the UTILITY menu.
7. Using the **SELECT/LOAD** encoder, scroll to the bottom of the list to the **Update Firmware** option.
8. Push in the **SELECT/LOAD** encoder, choose the **OK** option and push the **SELECT/LOAD** encoder again to start the update process .

Note: If Firmware Update option displays **Up To Date**, then you already have the latest versions of the firmware installed.
9. Wait until the update process has completed all 4 hardware components (Display MCU, Display Assets, Engine, and Control MCU). **DO NOT POWER OFF YOUR DEVICE DURING THIS PROCESS.**
10. Once completed, the device will automatically power cycle.