



◎ Shift Action( Sft + )

- ① Deck A Filter
- ② Deck A Key
- ③ FX 1 Dry / Wet
- ④ Deck A Play
- ⑤ Deck A SYNC
- ⑥ Deck A Pitch Fader
- ⑦ Deck A Hi EQ
- ⑧ Deck A Mid EQ
- ⑨ Deck A Low EQ
- ⑩ Deck A Cue
- ⑪ Deck A Monitor Cue
- ⑫ Deck A Volume
- ⑬ Deck B Hi EQ
- ⑭ Deck B Mid EQ
- ⑮ Deck B Low EQ
- ⑯ Deck B Play
- ⑰ Deck B Sync
- ⑱ Deck B Volume
- ⑲ Deck B Filter
- ⑳ Deck B Key
- ㉑ FX 2 Dry / Wet
- ㉒ Deck B Cue
- ㉓ Deck B Monitor Cue
- ㉔ Deck B Pitch Fader
- ㉕ X- Fader

- ㉖ Load Select Deck A  
Sft+ Adv.Panel Sel A (Move)
- ㉗ Load Select Deck B  
Sft + Adv.Panel Sel B (Move)
- ㉘ Load Select Preview  
Sht + Prev Play / Pause
- ㉙ Fav Select Prev  
Sft + Adv.Panel Sel A (Cue)
- ㉚ Fav Select Next  
Sft + Adv.Panel Sel B (Cue)
- ㉛ Track Select  
Sft + Track Select ( Wide )  
List Mode (Push)
- ㉜ Monitor Mix
- ㉝ Snap Mode On / Off
- ㉞ Master Volume

#### MIDI Page 1 (FX Unit 1)

- ㉖ Adv.FX 1 Dry / Wet  
Adv.FX Efx On (Push)  
Chain FX Dry / Wet
- ㉗ Adv.FX 1 Paramater 1  
Adv.FX Button 1 (Push)  
Chain FX Amount 1  
Sft + Chain FX Sel 1
- ㉘ Adv.FX 1 Paramater 2  
Adv.FX Button 2 (Push)  
Chain FX Amount 2  
Sft + Chain FX Sel 2
- ㉙ Adv.FX 1 Paramater 3  
Adv.FX Button 3 (Push)  
Chain FX Amount 3  
Sft + Chain FX Sel 3
- ㉚ Deck A Filte On / Off
- ㉛ Deck A Key On / Off
- ㉜ Deck A FX 1 On / Off  
Sft + FX Unit 1 Adv.Mode
- ㉝ Deck A FX 2 On / Off  
Sft + FX Unit 1 Chain.Mode

#### MIDI Page 2 (FX Unit 2)

- ㉖ Adv.FX 1 Dry / Wet  
Adv.FX Efx On (Push)  
Chain FX Dry / Wet
- ㉗ Adv.FX 1 Paramater 1  
Adv.FX Button 1 (Push)  
Chain FX Amount 1  
Sft + Chain FX Sel 1
- ㉘ Adv.FX 1 Paramater 2  
Adv.FX Button 2 (Push)  
Chain FX Amount 2  
Sft + Chain FX Sel 2
- ㉙ Adv.FX 1 Paramater 3  
Adv.FX Button 3 (Push)  
Chain FX Amount 3  
Sft + Chain FX Sel 3
- ㉚ Deck B Filte On / Off
- ㉛ Deck B Key On / Off
- ㉜ Deck B FX 1 On / Off  
Sft + FX Unit 1 Adv.Mode
- ㉝ Deck A FX 2 On / Off  
Sft + FX Unit 1 Chain.Mode

#### MIDI Page 3 (Deck A)

- ㉖ Loop Size Select  
Loop Active (Push)
- ㉗ Loop Move Size Sel  
Loop In (Push)
- ㉘ Loop Move ( Adv.Sel Move)  
Loop Out (Push)
- ㉙ Track Seek  
Loop Mode Sel (Push)
- ㉚ Hot Cue 1 Set + Store / jump  
Sft + Hot Cue 1 Delete
- ㉛ Hot Cue 2 Set + Store / jump  
Sft + Hot Cue 2 Delete
- ㉜ Hot Cue 3 Set + Store / jump  
Sft + Hot Cue 3 Delete
- ㉝ Hot Cue 4 Set + Store / jump  
Sft + Hot Cue 4 Delete

#### MIDI Page 4 (Deck B)

- ㉖ Loop Size Select  
Loop Active (Push)
- ㉗ Loop Move Size Sel  
Loop In (Push)
- ㉘ Loop Move ( Adv.Sel Move)  
Loop Out (Push)
- ㉙ Track Seek  
Loop Mode Sel (Push)
- ㉚ Hot Cue 1 Set + Store / jump  
Sft + Hot Cue 1 Delete
- ㉛ Hot Cue 2 Set + Store / jump  
Sft + Hot Cue 2 Delete
- ㉜ Hot Cue 3 Set + Store / jump  
Sft + Hot Cue 3 Delete
- ㉝ Hot Cue 4 Set + Store / jump  
Sft + Hot Cue 4 Delete