

## DN-C620 Firmware Update Instructions

Burn the DNC620up.bin file onto a CD-R using your burning software of choice. Once the update disc is created, follow the below instructions.

- (1) Power on the DN-C620.
- (2) Insert the update disc.
- (3) The update disc will be read.
- (4) Following message will be displayed.

Firmware Update  
A-1.11 OK?

- (5) Press the PUSH ENTER knob to start the update.
- (7) When the firmware update process is completed, the unit will reboot.
- (8) Turn off the power by pressing the POWER ON / OFF button, and remove the update disc from the CD drive.

### **Please Note:**

- **Do not turn off the power until updating is completed.**

If the firmware update is not successful, the unit may not operate properly and you will not be able to re upload the firmware. In this case service will be required.