



## DN-300R

Latest Firmware Version: 1.156

Release Date: June 1, 2018

## Firmware Update Instructions

### To update the firmware on your DN-300R:

1. Copy the downloaded firmware file to the root directory of a FAT32-formatted USB storage device and rename it **DR09.bin**.
2. Make sure your DN-300R is securely connected to a power outlet and is powered off.
3. Safely remove the USB storage device from the PC and then insert it into the **USB Port** on the front panel of DN-300R.
4. Press and hold the **Back** button while powering on DN-300R. DN-300R will automatically enter upgrade mode and begin the firmware update.

**IMPORTANT:** During the update process, **do not** power off DN-300R or disconnect it from the power outlet. Doing so can damage the unit.

5. When the firmware upgrade is complete, the unit may automatically reboot. If it does not automatically reboot, manually power the unit off and then back on to ensure completion of the firmware upgrade.

If the upgrade fails, it will show "**Upgrade Failed! Please reboot**".

## Changes

### Firmware Version 1.156 (June 1, 2018)

- Corrects clipping issue with RCA direct input and VU meter.

## Technical Support

For additional help, visit [denonpro.com/support](https://denonpro.com/support).