

Firmware Update Instructions

Updating the firmware on your PMD-526C requires a computer with a valid internet connection to download the firmware updater and an RS-232 cable to connect the computer to your PMD-526C.

1. Visit marantzpro.com and find the product page for PMD-526C to download and install the v2.10 firmware updater.
2. Connect PMD-526C to your computer using the **RS-232 Port** on the rear panel.
3. Set the **Operation Switch** on the rear panel of PMD-526C to the **Update** position.
4. Power on PMD-526C.
5. Open the firmware updater on your computer.
6. On the first page, under **Port Name**, select the **COM** port and then press **Next**.
7. The updater will show "The target is readable." Press **Next** to continue.
8. On the following page, your device will be selected in the target list. Press **Next** to continue.
9. Click the folder icon under **Download to device** and select the firmware **.HEX** file. Click **Next** to begin updating the PMD-526C firmware.
10. The firmware updater will show a progress bar as the unit is updated and display a message when the firmware has been updated successfully.
11. Once finished, close the firmware updater, power off PMD-526C and return the **Operation Switch** to the **Normal** position.
12. To check the firmware version on PMD-526C, power on PMD-526C, press and hold the **Jog dial** to enter the menu, then turn the **Jog dial** or use the **</>** buttons to navigate to **System Version**. Press the **Jog dial** to enter the menu option and view the current firmware version.

Changes

Firmware Version 2.16 (October 2019)

- Resolves issue where unit becomes unresponsive when sending continuous (every second or less) RS-232 commands.

Firmware Version 2.10 (June 2018)

- Resolves issue with Power On Play.

Technical Support

For additional help, visit marantzpro.com/support.