

# ***EWI 4000s*** ELECTRIC WIND INSTRUMENT

## Preset Program List

1 Singing Saw	26 TrainToHastings	51 Deep Bass	76 Pitchy
2 J-Judd	27 BuffyCramdon	52 Detune Pulse	77 Detune Saw
3 Sumo	28 Saw -4	53 DuckSauce	78 DirtyDown4th
4 Wood Wind	29 Square 90% Width	54 Warm Detune	79 DarkBass
5 Mimi	30 Fat Saw	55 Dual PWM	80 Warm Detune
6 Pulse Brass	31 Ambient Brass	56 Bright Synth	81 Singing Saw
7 Double Reed	32 Judd4000	57 M EWI	82 J-Judd
8 SoulSaw-4	33 Gross Saw	58 Wood Wind 2	83 Sumo
9 Mellow	34 Dual Pulse	59 DownNDirty	84 Wood Wind
10 Nightcrawler	35 Soprano	60 Earthy	85 Mimi
11HowLowCanYouGo	36 Funky Cry Baby	61 Edgy Pulse	86 Pulse Brass
12 Fat Bottom	37 NYStreets-3rd	62 Square Wave Wah	87 Double Reed
13 Funky Wah	38 Square 75% Width	63 Reed	88 SoulSaw-4
14 Bright Wah	39 FatterSaw	64 Feedbacker	89 Mellow
15 Recorder	40 Saw+5	65 Fat PWM	90 Nightcrawler
16 Mix Lead	41 Clear Saw	66 Smooth Synth	91HowLowCanYouGo
17 SpiritVoice 5th	42 Synth Solo	67 Wide PWM	92 Fat Bottom
18 Tuba	43 Cantabile Saw	68 Saxy	93 Funky Wah
19 Solid Brass	44 Stonehenge	69 Oxygen	94 Bright Wah
20 Squids+5	45 Crispy	70 Common Fanfare	95 Recorder
21 Pipe	46 Square 10% Width	71 ClareInNet	96 Mix Lead
22 Tonette	47 Soft Pulse	72 YawnHummer+5	97 SpiritVoice 5th
23 OctaveSteps	48 Silky	73 Mass Ave.	98 Tuba
24 SteamPipe	49 Espresso	74 Dual Pulse	99 Solid Brass
25 Square 50% Width	50 WoodNGlue	75 New Wood	100 Squids+5

Programs #81 - #100 are duplicates of Programs #1 - #20

