



MAX25

Latest Firmware Version: 1.12

Release Date: June 16, 2014

Firmware Update Instructions

1. Unzip the contents of **Akai Pro MAX25 Firmware Update v1.12.zip** to your Desktop.
2. Install **MIDI Updater v1.05**:
 - **Windows**: Double-click the **.exe** file and follow the on-screen instructions.
 - **Mac OS X**: Double-click the **.dmg** file, and then open the **Read Me** file and follow the instructions in the file.
3. Connect MAX25 to your computer's USB port, and ensure MAX25 is powered on.
4. Open the **MIDI Updater** application.
5. Click and drag the **MAX25_v1_12.upd** file into the MIDI Updater window. The update will begin. (Alternatively, go to **File>Open**, and then locate and open the **.upd** file.)
6. When the update is completed, MAX25's display will show the checksum numbers **10/12** and instruct you to press **Enter** to restart it. Press **Enter** to restart your MAX25.
7. Congratulations! Your MAX25 now has the newest operating system!

Changes Since Firmware Version 1.02

- Corrections to text labels for Transport and other assignable control values in HUI Mode
- Fixes toggle behavior for buttons in Mackie Control Mode or HUI Mode
- Fixes issue where enabling Arpeggiator could cause odd note behavior sent to the five-pin MIDI out port
- Improvement to pad LED handling for banking and toggle setting
- Triple-pressing the **Stop** button now sends an All Notes Off message to the five-pin MIDI Out
- CV/Gate Out settings are now saved in Global Settings

Technical Support

For additional help, visit akaipro.com/support.