

BOX CONTENTS (English)
CONTENIDO DE LA CAJA (Español)
CONTENU DE LA BOÎTE (Français)
CONTENUTI DELLA CONFEZIONE (Italiano)
LIEFERUMFANG (Deutsch)

v1.1



Note: Kick pedal and Hi-hat stand not included.
Nota: Pedal del bombo y soporte de hi-hat no están incluidos.
Remarque : Pédales de grosse caisse et support de charleston ne sont pas fournies.
Nota: Pedale della cassa e il hi-hat supporto de charleston non sono inclusi.
Hinweis: Kickpedal und das Hi-Hat-Stände sind nicht im Lieferumfang enthalten.

Drum key
Llave de ajuste de tambores
Clé de batterie
Chiave di accordatura
Stimm Schlüssel

A



Inner Vertical Post
Poste vertical interno
Montant vertical intérieur
Asta verticale interno
Innen Vertikalstrebe

B



31.88" / 810 mm

Module Crossbar
Barra transversal del módulo
Barre horizontale pour module
Traversa del modulo
Modul-Querstange

E



13.8" / 350 mm

Clamp
Abrazadera
Bague de fixation
Morsetto
Klemme

F



Mesh Tom Drums
Tambores toms de malla
Toms en peau maillée
Tamburi Tom a rete
Mesh Tom-Drums

I



10" / 254 mm

Mesh Snare Drum
Tambor redoblante de malla
Caisse claire avec peau maillée
Rullante a rete
Mesh Snare-Drum

J



12" / 305 mm


C



28.0" / 710 mm

Outer Vertical Post
Poste vertical exteriores
Montant vertical extérieurs
Pali di supporto verticale esterni
Äußere Vertikalstrebe

D



16.1" / 410 mm


Crossbars
Barras transversales
Barres horizontales
Traverse
Querstangen

G



L-Rod
Varilla en forma de "L"
Tige de fixation en L
Asta a L
L-Stange

H



Cymbal Arm
Brazo tipo para platillos
Perche pour cymbale
Braccio della piatto
Becken-arm

K



ARC Cymbal 12 (Crash)
Platillo ARC 12 (Crash)
Cymbale ARC 12 (Charleston)
Piatto ARC 12 (Crash)
ARC Becken 12 (Crash)


L



ARC Cymbal 14 (Ride)
Platillo ARC 14 (Ride)
Cymbale ARC 14 (Ride)
Piatto ARC 14 (Ride)
ARC Becken 14 (Ride)

Snare Stand Base
Base del soporte del redoblante
Support de caisse claire
Base per rullante
Snare-Ständerbasis

M




Snare Stand Top
Parte superior del soporte del redoblante
Bras de support de caisse claire
Parte superiore del rullante
Snare-Ständerbasis

N



ARC Hi-hat Controller
Controlador de hi-hat ARC
Basculeur pour cymbale charleston
Controller Hi-hat ARC
ARC Hi-Hat Controller

Q



Kick Drum Tower
Soporte del bombo
Grosse caisse
Torre per grancassa
Kick-Drum-Turm

R



8" / 203 mm


Trigger Cable Snake
Manojo de cables disparadores
Câble multipaire pour déclencheur
Multicavo trigger
Trigger-Kabelschlange

U



Screws
Tornillo
Vis
Vite
Schraube

V



Y



Connector Caps
Tapas de conector
Capuchons de connecteur
Tappi di collegamento
Anschlusskappen

O



Hi-hat Clutch
Fijación del hi-hat
Cymbale Charleston
Frizione Hi-Hat
Hi-Hat-Klammer

P



12" / 305 mm

ARC Hi-hat Cymbal 12
Controlador de platillo ARC 12
Contrôleur ARC pour cymbale charleston 12
Piatto Hi-hat ARC 12
ARC Hi-Hat-Becken 12

S



CORE Drum Module
Módulo de batería CORE
Module de percussion CORE
Modulo batteria CORE
CORE Drum-Modul

T



Module Mount
Placa de soporte del módulo
Support pour module
Montaggio del modulo
Modulfassung

W



Power Adapter
Adaptador de alimentación
Adaptateur d'alimentation
Adattatore di alimentazione
Netzteil

X



Cable Wraps
Envolturas de cable
Enroulements de câble
Avvolgicavi
Kabelumwicklungen



ALESIS.COM/SUPPORT