


## EXPLODED VIEWS



**WARNING:**  
Parts marked with this symbol ⚠ have critical characteristics.  
Use ONLY replacement parts recommended by the manufacturer.

⚠印の部分は安全を維持するために重要な部品です。従って交換時は必ず指定の部品を使用してください。

## PARTS LIST OF EXPLODED VIEW

\* 本表に記載されている部品は、補修用部品のため製品に使用している部品とは一部、形状、寸法などが異なる場合があります。

\* The parts listed below are for maintenance only, might differ from the parts used in the unit in appearances or dimensions.

\* "nsp" 印の部品は常時在庫していませんので供給に長時間を要することがあります。場合によっては、供給をお断りする場合があります。

\* Part indicated with the mark "nsp" are not always in stock and possibly to take a long period of time for supplying, or in some case supplying of part may be refused.

**Note:** The symbols in the column "Remarks" indicate the following destinations.

E2 : Europe model

E3 : U.S.A. & Canada model

|   | Ref. No. | nsp | Part No.         | Part Name                       | Remarks | Q'ty | New |
|---|----------|-----|------------------|---------------------------------|---------|------|-----|
| ⚠ | 1        | nsp | 00D 958 7064 007 | FRONT BOARD ASS'Y               |         | 1    | *   |
|   | 2        | nsp | 00D 958 7064 104 | MIXER PCB ASS'Y                 |         | 1    | *   |
|   | 3        | nsp | 00D 958 7064 201 | BOOTH PCB ASS'Y                 |         | 1    | *   |
|   | 4        | nsp | 00D 958 7064 308 | OUTPUT PCB ASS'Y                |         | 1    | *   |
|   | 5        | nsp | 00D 958 7064 502 | POWER PCB ASS'Y                 | E2      | 1    | *   |
|   | 5        | nsp | 00D 958 7064 405 | POWER PCB ASS'Y                 | E3      | 1    | *   |
|   | 6        | nsp | 00D 958 7064 609 | CPU PCB ASS'Y                   |         | 1    | *   |
|   | 7        |     | 00D 958 7064 706 | CROSS FADER & FIXED PLATE ASS'Y |         | 1    | *   |
|   | 8        | nsp | 00D 958 7064 803 | HEADPHONE PCB ASS'Y             |         | 1    | *   |
| ⚠ | 9        | nsp | 00D 958 7065 006 | CH VR PCB ASS'Y                 |         | 4    | *   |
|   | 10       | nsp | 00D 958 7065 103 | LEVER METER PCB ASS'Y           |         | 1    | *   |
|   | 11       | nsp | 00D 958 7046 504 | CORD BUSH(SZ)                   |         | 1    | *   |
|   | 12       |     | 00D 958 7045 505 | PUSH KNOB                       |         | 5    | *   |
|   | 13       |     | 00D 958 7045 602 | ROTARY KNOB(ABS)                |         | 6    | *   |
| ⚠ | 14       |     | 00D 958 7045 709 | ROTARY KNOB(ABS)                |         | 23   | *   |
|   | 15       |     | 00D 958 7045 903 | TRANSPARENT MEDIA ADAPTER       |         | 1    | *   |
|   | 16       |     | 00D 958 7046 009 | SQUARE KNOB                     |         | 16   | *   |
|   | 17       |     | 00D 958 7046 106 | JACKET                          |         | 1    | *   |
|   | 18       |     | 00D 958 7046 203 | LARGE ROTARY KNOB(ABS)          |         | 2    | *   |
| ⚠ | 19       |     | 00D 958 7046 300 | SMALL ROTARY KNOB(ABS)          |         | 6    | *   |
|   | 20       |     | 00D 958 7046 407 | SQUARE PUSH KNOB                |         | 7    | *   |
|   | 21       |     | 00D 958 7013 605 | GROUND PIN                      |         | 2    | *   |
|   | 22       |     | 00D 958 7047 707 | VR BOARD(IRON,2t)               |         | 1    | *   |
|   | 23       | nsp | 00D 958 7046 708 | FIXED PLATE FOR IC(SECC,1t)     |         | 1    | *   |
| ⚠ | 24       |     | 00D 958 7047 309 | CH FIXED PLATE                  |         | 4    | *   |
|   | 25       |     | 00D 958 7046 805 | FRONT PANEL                     |         | 1    | *   |
|   | 26       | nsp | 00D 958 7047 406 | BOTTOM BASE                     |         | 1    | *   |
|   | 27       | nsp | 00D 958 7047 008 | BACK COVER                      | E2      | 1    | *   |
|   | 27       | nsp | 00D 958 7047 105 | BACK COVER                      | E3      | 1    | *   |
| ⚠ | 28       | nsp | 00D 958 7046 902 | BACK BOARD                      |         | 1    | *   |
|   | 29       |     | 00D 958 7047 503 | CH VR BOARD                     |         | 4    | *   |
|   | 30       | nsp | 00D 958 7047 600 | BRACKET TRANSFORMER             |         | 2    | *   |
|   | 31       |     | 00D 958 7015 302 | POWER SW                        |         | 1    | *   |
|   | 32A      |     | 00D 958 7051 502 | AC POWER CORD(VDE TYPE)         |         | 1    | *   |
| ⚠ | 32B      |     | 00D 958 7051 405 | AC POWER CORD(UL TYPE)          |         | 1    | *   |
|   | 33       |     | 00D 958 7052 404 | TRANSFORMER(AC230V)             | E2      | 1    | *   |
|   | 33       |     | 00D 958 7052 307 | TRANSFORMER(AC115V)             | E3      | 1    | *   |
|   | 34       |     | 00D 958 7056 002 | 0.01uF/250V,M,BULK 16,Y5V       |         | 1    | *   |
|   | 35       |     | 00D 958 7061 107 | RCA ADAPTOR PLUG(A028)          |         | 4    | *   |
| ⚠ | 36       |     | 00D 958 7061 903 | DECORATION                      |         | 1    | *   |
|   | 37       |     | -                | NUT(M3*P0.5)                    |         | 2    |     |
|   | 38       |     | 00D 958 7039 508 | WASHER(8*3.2*1t,NI)             |         | 2    |     |
|   | 39       |     | 00D 958 7063 600 | SPRING                          |         | 2    |     |
|   | 40       | nsp | 00D 958 7063 804 | HIMILON                         |         | 5    |     |
| ⚠ | 41       |     | 00D 958 7063 901 | MAT FORBASE                     |         | 4    |     |
|   | 42       | nsp | 00D 958 7063 707 | CUSHION                         |         | 7    | *   |
|   | 43       | nsp | 00D 941 0019 501 | SCREW(M3*8,P=0.5,BLACK)         |         | 13   |     |
|   | 44       | nsp | 00D 958 7063 406 | SCREW((PTP,M3*10)               |         | 9    |     |