

HeadRush Pedalboard

Latest Firmware Version: 2.1.2

Release Date: May 2020

Minimum System Requirements

- Windows 7 (32- or 64-bit) or macOS 10.11
- Host USB 2.0 port

File Backup Instructions

Important: Please back up all of your current rig, setlist, model preset, loop and/or impulse response (IR) files from HeadRush Pedalboard to your computer before updating the firmware.

1. Connect your computer to the HeadRush Pedalboard's **USB port** using a standard USB cable.
2. With your computer powered on, power on the HeadRush Pedalboard using the **power switch**.
3. Tap the **•••** button in the upper-right corner of the screen and then tap **Global Settings**.
4. In the **Global Settings** page, tap the **•••** icon in the upper-right corner, and then tap **USB Transfer**. On your computer, your HeadRush Pedalboard will appear as a mass-storage device called **HeadRush**.

Windows users: If this is the first time you've connected it to this computer, you may need to wait a minute while it installs the class-compliant drivers.

5. Open the **HeadRush** drive. You can now freely click and drag contents between **HeadRush** and your computer. Note that any changes you make to the contents of your **HeadRush** are immediate and cannot be cancelled.
6. **IMPORTANT:** When you are finished transferring contents, you must **unmount/eject** the HeadRush drive from your computer. File corruption may occur if the drive is not properly ejected before continuing.
7. After the drive has been ejected, tap **Sync** on your HeadRush Pedalboard to "commit" any changes you made to the contents of the HeadRush drive. An additional prompt will appear to confirm you have ejected the drive. Tap **Proceed** to continue or **Cancel** to continue accessing files on your computer.

As the HeadRush Pedalboard analyzes and imports the files, a meter on the display will indicate its progress. The normal Global Settings screen will reappear when the process is finished. Do not disconnect or power off HeadRush Pedalboard during the sync process.

Firmware Update Instructions

1. Connect the **USB port** on your HeadRush Pedalboard to your computer, and ensure HeadRush Pedalboard and your computer are powered on.
2. On your HeadRush Pedalboard, tap the **•••** icon in the upper-right corner, and tap **Global Settings**.
3. In the Global Settings screen, tap the **•••** icon in the upper-right corner again, and tap **Firmware Update**. In the screen that appears, tap **OK** to continue. After restarting, the screen will show **Update** at the bottom edge.
4. Open the **HeadRush Pedalboard 2.1.2 Updater** application for your operating system—Windows or macOS. (You may need to unzip an additional .zip file to access the actual application.)
5. When the updater window appears, click **Update HeadRush Pedalboard**. Do **not** disconnect or power off HeadRush Pedalboard or your computer until the update is completed.
6. When the update is completed, the updater window will display **Done**, and your HeadRush Pedalboard will restart. Click **Done** to close the updater window.
7. Confirm your HeadRush Pedalboard is using the latest firmware—tap the **•••** icon in the upper-right corner, and tap **Global Settings**. The firmware version will appear at the bottom of the screen as: **HEADRUSH v2.1.2.69a28e0, FIRMWARE V 01.21**.

Congratulations—your HeadRush Pedalboard now has the latest firmware!

For additional help, visit headrushfx.com/support

Changes

Since Firmware Version 2.1.1

- Added compatibility for macOS 10.15 (Catalina) to the macOS firmware updater
- Fixed a rare issue that could cause units to be stuck on the "Loading..." startup screen
- Fixed a rare issue that could cause unexpected parameter changes in Hands-Free Mode

Since Firmware Version 2.1.0

- Minor bug fixes

Since Firmware Version 2.0.0

- Added **3** new amp models to the **Amp** category:
 - 99 PV51 II LEAD
 - 99 PV51 II CRUNCH
 - 99 PV51 II CLEAN
- Added **140** new HeadRush Exclusive Cab IRs (impulse responses) to the **IR** category, based on the following cabinets:
 - 60S412A
 - WHITEMOON112C
 - WHITEMOON112OB
 - JR112
 - MKBASS212
 - TREAD212
 - TWIN212OB
- Added **3** new FX to the **Expression** category:
 - CHORD WHAM
 - FEED BACK
 - TIME WARP
- Added **2** new FX to the **Reverb/Delay** category:
 - REV DELAY
 - PIT DELAY
- Added **DROP TUNE** to the **Modulation** category.
- Added **ANXIETY OD** to the **Distortion** category.
- Added **NOISE FILTER** to the **Dynamics/EQ** category.
- Added the ability to save and load loops.
- Added the ability to configure scenes to load block presets.
- Added the ability to sort impulse response files using subfolders created in USB transfer mode.
- Added the ability to select lower intervals while using the **SMART HARM** effect.
- Added the ability to control the device using external MIDI CC messages.
- Minor bug fixes, DSP optimization and UI improvements.

Since Firmware Version 1.2.1

- Added **7** new amp models to the **Amp** category:
 - o 65 BLACK PRINCE
 - o 65 BLACK PRINCE REV
 - o 66 FLIP BASS
 - o 82 LEAD 800 50W
 - o 82 LEAD 800 TS MOD
 - o 85 M-2 LEAD CAP MOD
 - o 92 TREADPLATE RAW
- Added **160** new HeadRush Exclusive Cab IRs (impulse responses) to the **IR** category, based on the following cabinets:
 - o 60S 412
 - o BIRCH 115
 - o BIRCH 410
 - o BLACK LINE 810
 - o FAWN 212
 - o TANGERINE 212OB
 - o TANGERINE 412
 - o TREAD 412
- Added **3** new FX to the **Modulation** category:
 - o SMART HARM
 - o TRON FILTER
 - o RING MOD
- Added **2** new FX to the **Reverb/Delay** category:
 - o SHIMMER
 - o AIR DELAY
- Added **AUTO SWELL** to the **Dynamics** category.
- Enhanced the Setlist feature by adding the following:
 - o Added the ability to group preset rigs into **Songs** within a setlist.
 - o Added a new footswitch mode, **Song View**.
 - o Added **Classic** and **Advanced** options for viewing setlists on the 7" touch screen in **Song View**.
- Added the following options to the **Global Settings** page:
 - o Added the option to reverse **Hybrid View**.
 - o Added options to customize the overall color scheme used on the touch screen and LEDs.
- Added the ability to save in **Hands-Free Mode** by using a footswitch.
- Added the ability to toggle reverb and delay tails per effect within a rig.
- Added the ability to save expression pedal state (A/B) per rig.
- Added the ability to touch and drag to navigate parameters displayed on the 3 parameter knobs.
- Additional DSP optimization and UI improvements.

Since Firmware Version 1.2.0

- Minor bug fixes.

Since Firmware Version 1.1.1

- Added **Octaves** effect to the **Modulation** model category.
- Added **Global EQ** settings to the **Global Settings** page.
- Added the ability to quickly select and audition impulse response files in Hands-Free Mode using foot-switches.
- Added the ability to select **IR (1024)** as an alternate output on the **Global Settings** page.
- Significantly reduced rig-switching time.
- The current view (**Stomp View**, **Rig View**, **Hybrid View**, or **Setlist View**) is now retained when you power off HeadRush Pedalboard.
- Minor bug fixes and DSP optimizations.

Since Firmware Version 1.1.0

- Minor bug fixes.

Since Firmware Version 1.0.2

- Added **59 Tweed Prince** to the **Amp** model category.
- Added **Air Vibrato** effect to the **Modulation** model category.
- Added **More Wah** effect to the **Expression** model category.
- Added **Panner** effect to the **Expression** model category.
- Added **Gate** effect to the **Dynamics/EQ** model category.
- Added the ability to import **.tfx** (Eleven[®] Rack) presets.

To import a .tfx preset, click and drag it to the **Rigs** folder when connected to a computer and the HeadRush Pedalboard is in USB Transfer mode, and then tap **Sync**.

- Added the ability to customize the text on an OLED screen for a footswitch set to Stomp Mode.

To change the OLED text for a footswitch in Stomp Mode, enter the **Hardware Assign** page, and then tap the outlined box that shows the current OLED text for one of the 8 footswitches.

- Added Scene feature, which is the ability to assign a single footswitch to control the **On/Off** parameter for multiple models.

To assign a single footswitch to control the On/Off parameter for multiple models, enter the **Hardware Assign** page, and then tap the **Toggle/Hold** parameter for one of the 8 assignable footswitches until it says **Scene**. Then, tap the **Edit** text that appears on the footswitch to set which models will be turned on/off when pressing the footswitch.

- Added the ability to make fine adjustments in Hands-Free Mode by using the two bottom-right footswitches labeled **-** and **+**.
- Added the ability to delete models from the main screen by dragging and dropping them onto a **Drag to Delete** bar that appears at the bottom of the screen.
- Added the ability to select **44.1kHz** as a sample rate for USB Audio.
- Added the ability to use a search bar for faster access to finding rigs while creating or editing a setlist.
- Minor bug fixes and DSP optimizations.

Since Firmware Version 1.0.1

- Added **Screen Lock** feature. This feature disables the touchscreen, and gives you a simple interface that shows your current rig name, setlist name, and a customizable image.

To customize the Screen Lock image, while the HeadRush Pedalboard is in USB Transfer mode, place a **.png**, **.bmp**, **.jpg**, or **.jpeg** file named **LockScreenLogo** in the root directory of the **HeadRush** drive. We recommend using a **800x400**-pixel image (it will be automatically scaled to this size after transferring it).

- Added the ability to place the looper before or after your signal chain. This gives you the ability to record a riff, and then place it before the signal chain so you can sculpt your rig's sound without having to physically play the riff over and over again.

To set the looper's location, while viewing the looper on the touchscreen, turn the third **parameter knob (Loc)** to place it before (**Pre**) or after (**Post**) the signal chain.

- Added ability to truncate impulse response (IR) files to **1024** samples. When your IRs are truncated, they require fewer DSP resources, which frees up more resources to load additional models and/or IRs to each rig.

To load a truncated IR, select **IR 1024** instead of the normal IR setting when adding an IR to a rig.

- Added the ability to enable or disable confirmation messages that appear while changing your rig.

To enable or disable these messages, enter the **Global Settings** screen and set **Reminders > Confirm Unsaved** to **On** (enabled) or **Off** (disabled).

- Added **Side Comp** effect to the **Dynamics/EQ** model category. This is a side-chain compressor effect, which uses the HeadRush Pedalboard's effects return as the side-chain input.

Note: When this effect is in your signal chain, the FX Loop will be disabled.

- Minor bug fixes and DSP optimizations.

Since Firmware Version 1.0.0

- Enabled USB audio recording and reamping features.

Important Note for Windows Users: Visit headrushfx.com/support and download and install the latest Windows driver before using the USB Audio feature.

- Minor bug fixes.